

## Maintenance Treatments

### Application Frequency:

1. We recommend maintenance treatments (hi-touch points, other targeted surfaces) monthly or more often based on surface use.
2. The product is exceptionally durable but can be removed by abrasion, so base your maintenance treatment frequency on the surface use and high abrasion locations.
3. Pro Tip: If you feel the finish of the surface may have been removed, it is likely PreventX 24/7™ has been removed with it. Reapply to provide coverage over those areas.

### Where to Use:

1. Use on hard and soft surfaces.
2. Typical maintenance treatment surfaces include, but are not limited to doorknobs, handles, desks, countertops, tables, condiment holders, salt & pepper shakers, pencil sharpeners, faucet handles, light switches, computer keyboards, mice, telephones, remotes, appliances, steering wheels, keys, fob's, railing, chairs, athletic equipment, toys, bus seats and railings, lamps, tray tables, bedside tables, blood-pressure cuffs, bed rails, toilets, game controllers, vertical surfaces like walls, desk sides, chair legs, etc.
3. Do not use on food-contact surfaces such as utensils, cutting boards, slicers, pot-stocks, and surfaces that food regularly contacts during preparation.

### Supplies Needed:

1. PreventX 24/7™ – 32oz bottle with standard trigger sprayer or a fine-mist sprayer.
2. Fine-mist handheld or backpack sprayer with a nozzle size of 40 microns or less.
3. A microfiber cloth is recommended to wipe off any excess drips and runs that is visible after treatment
4. PreventX SCT or a cleaner to wipe down surfaces that were not adequately cleaned.

### Surface Preparation:

1. Ensure that the surface is clean and free from debris, oils, grease, and organic material.
2. We recommend using our *PreventX SCT* to clean the surface to ensure maximum adhesion to the surface.
3. If using soap/water or any other cleaner and/or disinfectant before application, allow surface to dry before applying PreventX 24/7™.

### Application of PreventX 24/7™:

1. Apply PreventX 24/7™ evenly over the surface being treated to ensure that the entire surface is covered/wetted during application. When treating on or near electronics, apply directly to the cloth and wipe onto the surface.
2. Allow the surface to air dry in temperatures up to 320° until it is dry to the touch. If needed, the product can be wiped away after being on the surface wet for 5 minutes.
3. Using a microfiber cloth, wipe any excess product which is visible (i.e., drips, runs, etc.)
4. The treated surface is ready for use when the surface is dry to the touch.
5. Pro Tip: Regular cleaning and disinfecting will NOT remove the PreventX 24/7™ surface finish.
6. Remove children and pets from the treated area until completely dry.